Accessories

Fan




Ordering Key

- Qty: 10 pcs per bag
- 24VDC supply

RFAN4024X10

Fan Mounting Instructions



The RSGD..37.. and RSGD..45.. models can be equipped with a fan if more starts/hr (than what specified in the datasheet) are required. Connect the fan as shown in the diagram. The fan needs an external supply of 24VDC – the (+) supply needs to be connected to the red wire and the (-) supply needs to be connected to the black wire.

It is important to connect the fan to the correct supply polarity as failure to do so will cause the fan to rotate in the wrong direction possibly damaging the semiconductors due to over-temperature.